



C

**BUNKER
DELIVERY
AREA**

A

**OUTSIDE
SECA**

B

SECA

PILOT LIMITS

PILOT LIMITS

SOFT FAN SOUNDING	SOFT FAN SOUNDING	SOFT FAN SOUNDING	SOFT FAN SOUNDING	SOFT FAN SOUNDING
01	350	01	00	-6
02	342	04	02	-5
03	323	06	03	-4
04	323	08	03	-3
05	318	01	01	-2
06	325	01	00	-1
07	355	01	00	0
08	123	01	01	+1
09	146	03	01	+2
10	152	04	02	+3
11	146	04	02	+4
12	138	03	01	+5
13	138	03	01	+6
14	138	03	01	+6
15	138	03	01	+6

AREAS
placed on the
nautical areas at
and to exercise